

6282464

1/17




FIG. 1

2/17




FIG. 2

3/17




FIG. 3

4/17




FIG. 4




FIG. 5A

6/17

TO  
STEP 340  
IN FIG. 5A

TO  
STEP 320  
IN FIG. 5A

FROM  
STEP 323  
IN FIG. 5A

(A)

(B)

(C)




FIG. 5B

7/17




FIG. 6




FIG. 7

8/17

209




FIG. 8




FIG. 9

002220 E249560



9/17

209




FIG. 10




FIG. 11

09/355433

10/17

209




FIG. 12

209




FIG. 13

11/17




FIG. 14



13/17




FIG. 15B




FIG. 16




FIG. 17




FIG. 18




FIG. 19

16/17

209

ENTER LETTER OR ITEM NAME:

AIR CONDITIONING

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	P
Q	R	S	T	U	V	W	X
Y	Z						

DONE

1705

1701

1703

FIG. 20

209

INDEX

AIR CONDITIONING

ANTI-LOCK BRAKE SYSTEM INDICATOR

AUTOMATIC CLIMATE CONTROL

AUTOMATIC TRANSMISSION

SHIFT LEVER POSITION INDICATOR

1805

PREVIOUS

1801

1803

FIG. 21



17/17

1901			1903		
1905	AIR CONDITIONING	LINK TO CLIMATE CONTROL SCREEN OF FIG. 18			
	ANTI-LOCK BRAKE SYSTEM INDICATOR	LINK TO WARNING LIGHT OPTION #4 ON FUEL /TEMP SCREEN (NOT SHOWN)			
	AUTOMATIC CLIMATE CONTROL	LINK TO CLIMATE CONTROL SCREEN OF FIG. 18			
	CHARGING SYSTEM FAILURE INDICATOR	LINK TO CHARGING SYSTEM FAILURE OPTION 1309f (FIG. 16)			
	CLIMATE CONTROL SYSTEM	LINK TO CLIMATE CONTROL SCREEN OF FIG. 18			
	COOLING	LINK TO CLIMATE CONTROL SCREEN OF FIG. 18			
	CRUISE CONTROL INDICATOR	LINK TO WARNING LIGHT OPTION #2 ON SPEEDOMETER SCREEN (NOT SHOWN)			
	DEFOG/DEFROST	LINK TO CLIMATE CONTROL SCREEN OF FIG. 18			
	DOOR AJAR INDICATOR	LINK TO WARNING LIGHT OPTION #7 ON FUEL/TEMP SCREEN (NOT SHOWN)			
	DIRECTIONAL SIGNALS INDICATOR	LINK TO TURN SIGNAL/HAZARD WARNING OPTION 1201b (FIG. 15A)			

FIG. 22